



BARREL PUMP TROUBLESHOOTING GUIDE

TROUBLESHOOTING GUIDE:

Barrel Pump with Injector System

ISSUE	SOLUTION
Controller shows E3	Check if pump is running. If injectors are firing, replace pressure switch. If injectors are not firing, check grease level. If grease is present, replace vent valve.
Controller displays E5	Change setting in menu#18 to Lo-C.
Pump does not turn on	Check to see if voltage is present on pin 7 and 12. Check that wiring matches diagram. Replace Pump.
Alarm operates continuously during normal operation	Change setting in menu#16 to Cont.