

DIRT TRAP ELEMENT REPLACEMENT INSTRUCTIONS

Step 1: Depressurize any residual pressure from the system.

Step 2: Remove the old filter element from the filter body. Figure 1.1

Step 3: Remove the old Filter Element's Seal from the bottom of the Filter Body. Throw away. Visually inspect the inner body for any debris that may have fallen in during disassembly. Refer to Figure 1.2

Step 4: Lightly lubricate the new Dirt Trap Element Seal & O-Ring with oil or grease and drop the seal in the filter body making sure it rests flat on the body floor above the inlet cavity. Refer to Figure 1.2

Step 5: Insert the new Dirt Trap Replacement Element into the filter body. Tighten until the element assembly bottoms out onto the filter housing. Figure 1.3

Tech Support: Can't figure it out? Give us a call toll free at: (877) 452-0157

Figure 1.1



Figure 1.2



Figure 1.3

