



## PLUNGER INSTALLATION GUIDE FOR LPE-ECP-24 SERIES

**WHAT YOU'LL NEED:** LPE PUMP, LPE-XP32 PLUNGER ASSEMBLY, AND CRESCENT WRENCH


**STEP 1:** REMOVE YOUR PLUNGER ASSEMBLY FROM THE PLASTIC CONTAINER. NOTE THE PLUNGER COMPONENTS AS SHOWN BELOW. THERE ARE THREE NOTCHES ON THE PLUNGER SHAFT. PULL PLUNGER OUT TO THE SECOND NOTCH AS SHOWN.



## PLUNGER INSTALLATION GUIDE FOR LPE-ECP-24 SERIES

**STEP 2:** TAKE YOUR PUMP AND LOOK THROUGH THE TOP LUBRICATION SLOTS. NOTICE A TRACKED DISK IN BETWEEN THE SLOTTED TOP PORTION AND THE FLOOR OF THE PUMP AS SHOWN. **WHEN PROPERLY INSTALLED, THE PLUNGER TIP WILL SIT IN THIS TRACK.**

TRACKED DISK





## PLUNGER INSTALLATION GUIDE FOR LPE-ECP-24 SERIES

**STEP 3:** TAKE YOUR PLUNGER ASSEMBLY THAT HAS THE PISTON YOU PULLED OUT TO THE SECOND NOTCH AND INSERT THE PLUNGER ASSEMBLY INTO THE PUMP BODY AT ABOUT A 30 DEGREE ANGLE UPWARDS CLEARING THE DISK FROM THE TIP. ONCE YOU INSERT TO THE THREADS OF THE PLUNGER ASSEMBLY, STRAIGHTEN OUT, **ENSURE THE PLUNGER TIP SEATS INTO THE TRACK.** THREAD THE PLUNGER ASSEMBLY INTO THE PUMP HOUSING UNTIL HAND TIGHT. USE A WRENCH TO TIGHTEN THE REST OF THE WAY. SEE ILLUSTRATION BELOW. CHECK AGAIN TO ENSURE TIP REMAINS IN THE TRACK.



**ENSURE TIP SEATS WITH THE TRACK**

